



Mac Powerbook 140 Battery Replacement

Learn how to replace the battery on your Macintosh Powerbook 140.

Written By: Jack



POWERSMART



Roll over image to zoom in

PowerSmart® 6V 4200mAh Ni-MH Battery for APPLE PowerBook 145B, 165c, 180c, 661-0013, 661-0754, 661-0789, M5417, M5545, M5545LL/A, M5545LL/C, M5653, M5654

from PowerSmart

[Be the first to review this item](#)

List Price: \$88.99

Price: **\$39.99** + \$5.49 shipping

You Save: **\$49.00 (55%)**

Note: Not eligible for Amazon Prime.

Only 13 left in stock.

Ships from and sold by [power198](#).

Estimated Delivery Date: Oct. 30 - Nov. 17 when you choose Standard Shipping at checkout.

- Battery Type: Ni-MH ///Voltage: 6.00V ///Capacity: 4200mAh ///Color: Grey///Dimension: 103.30 x 101.80 x 20.10 mm///Weight: 496.13 g
- Product Type: Replacement Battery (Brand New) ///Condition: New, 1 year warranty!
- Dimension: 103.30 x 101.80 x 20.10 mm///Weight: 496.13 g
- Please ensure the product(s) that you are going to buy fits the brand, model, part number and dimension (mentioned above) of your device.
- The brand "PowerSmart®" is our exclusive registered trademark, products trademarked " PowerSmart®" are marketed and sold exclusively by power198

[3 new](#) from **\$39.99**

INTRODUCTION

Follow this guide to replace the hard drive in your Macintosh Powerbook 140 computer. Always ensure all of your parts are compatible and will not damage your computer or pose any health or safety hazards. Always make sure you keep track of all parts. Wash hands thoroughly after handling components. Most of all, USE COMMON SENSE.

NOTE- I am no computer expert. Please notify me of any errors or necessary changes. Thanks!


ALSO: **I do not own any of the images used in this guide!** The images are the sole property of their respective owners. I am simply using them to assist in demonstrating the steps of this guide



PARTS:

- [Macintosh Powerbook 140 compatible battery](#) (1)
-

Step 1 — Aquire Battery



Roll over image to zoom in

PowerSmart® 6V 4200mAh Ni-MH Battery for APPLE PowerBook 145B, 165c, 180c, 661-0013, 661-0754, 661-0789, M5417, M5545, M5545LL/A, M5545LL/C, M5653, M5654
from [PowerSmart](#)
[Be the first to review this item](#)

List Price: \$88.99
Price: **\$39.99** + \$5.49 shipping
You Save: **\$49.00 (55%)**

Note: Not eligible for Amazon Prime.

Only 13 left in stock.
Ships from and sold by [power198](#).

Estimated Delivery Date: Oct. 30 - Nov. 17 when you choose Standard Shipping at checkout.

- Battery Type: Ni-MH ///Voltage: 6.00V ///Capacity: 4200mAh ///Color: Grey///Dimension: 103.30 x 101.80 x 20.10 mm/Weight: 496.13 g
- Product Type: Replacement Battery (Brand New) ///Condition: New, 1 year warranty!
- Dimension: 103.30 x 101.80 x 20.10 mm/Weight: 496.13 g
- Please ensure the product(s) that you are going to buy fits the brand, model, part number and dimension (mentioned above) of your device.
- The brand "PowerSmart®" is our exclusive registered trademark, products trademarked "PowerSmart®" are marketed and sold exclusively by power198

[3 new from \\$39.99](#)

- Begin by locating the correct type of battery. A simple internet search or a glance at Amazon.com should bring the right results. **BE SURE THAT THE BATTERY IS COMPATIBLE WITH THE COMPUTER.** Not doing so could result in injury.

Step 2 — Remove Original Battery



- Slide the battery panel (or switch, depending on the battery) on the left side of the computer so the battery is in the "Unlocked" position. Pull the battery straight out. Put in the new battery and slide the panel/switch to the "Locked" position.

It is not required, but I always find it useful to save the old battery, lest you need it later. Unless the battery is leaking, or poses some other health/safety issue(in which case dispose of it in the proper manner), store it in a battery-safe environment.

This document was last generated on 2017-07-14 02:07:19 PM.